DecoFrame Kit Classic Canopy

Installation Guide



01 Preparation

DecoFrame Kit Classic Canopy Components

ltem No.	Description
55 14 11 H	Gridline Aluminium Integra Profile for canopy
C 3000 H	C Channel 19 x 38mm
A WDN 21 H	T-bar hanger
A 345 H	Gridline Aluminium Integra Tegular 24/15 Profile corner post
A 348 G	Channel Bracket for Canopy (Aircraft cable included in the kit)
CA 97 H	Clamp for C channel
A 347 H	24mm Joggled connector clip
A 346 J	15mm Joggled connector clip
A 339 K	Universal T-bar connector clip for cut tees with screws

DecoFrame Kit Classic Canopy is a modular suspension system supplied kit with ready-to-assemble components (partly listed above).

Initial Recommendations


- // DecoFrame Kit Classic Canopies should always be installed in accordance with all applicable building codes and regulations.
- DecoFrame Kit Classic Canopies, as any other architectural feature located in the ceiling plane, may obstruct or skew the existing or planned fire sprinkler distribution pattern or even delay the activation of the fire detection system. Designers and installers are advised to consult a fire protection engineer for guidance on the proper installation techniques where fire detection or suppression systems are present.
- // Any additional load (such as lighting) MUST NOT be suspended from the canopy but independently from the soffit.
- // DecoFrame Kit Classic Canopies should be always installed on a horizontal plane.
- // DecoFrame Kit Classic Canopies are only suitable for indoor applications.
- // DecoFrame Kit Classic Canopies can reach a significant weight. In order to minimise the risk of injuries, the canopies should be installed by a minimum of 2 people.
- ✓ Suspension elements such as threaded rods, anchors or any other element not included in the kit must be chosen to ensure a safe installation and follow local regulations.
- // It is recommended to assemble the canopy under the final ceiling location to avoid later movement.
- It is recommended wearing appropriate PPE when installing, for example: gloves, safety glasses, safety masks, safety boots and long sleeves.

Gloves supplied in the kit are used to prevent marking the components during installation. They are **NOT** meant to be used as safety gloves.


01 Preparation

Suspension Points


Suspension points should be determinded before installing the canopy. See the recommended suspension point matrix on the last page of this guide.



1.8 x 3m module



Gridline Aluminium Integra DecoFrame Kit Classic 55 14 11 H






Tegular24 Tegular15


112


The 1.8 x 3.0m module is used as an example only



4 Gridline Aluminium profiles / 4 corner posts









04 The Grid – Main Runner

The 1.8 x 3.0m module is used as an example only



clip A 339 K

T-bar hanger A WDN 21 H



07 Physical Data

Material

- Extruded aluminium profiles
- DecoFrame Kit Classic is made from extruded aluminium, offers better registration, handling capability and finished appearance compared with standard cold-rolled steel

Surface finish

- Polyester powder coated
- 💋 Global white

Warranty

// For more information, please see our website

Module	Grid system 15mm Joggled Item No.	Grid system 24mm Joggled Item No.		
1200 x 1200mm	AX 22 G15 A	AX 22 G24 A		
1800 x 1200mm	AX 32 G15 A	AX 32 G24 A		
1800 x 1800mm	AX 33 G15 A	AX 33 G24 A		
2400 x 1200mm	AX 42 G15 A	AX 42 G24 A		
2400 x 1800mm	AX 43 G15 A	AX 43 G24 A		
2400 x 2400mm	AX 44 G15 A	AX 44 G24 A		
3000 x 1200mm	AX 52 G15 A	AX 52 G24 A		
3000 x 1800mm	AX 53 G15 A	AX 53 G24 A		
3000 x 2400mm	AX 54 G15 A	AX 54 G24 A		
3000 x 3000mm	AX 55 G15 A	AX 55 G24 A		

Ceiling tiles are NOT included in the kit.

Max. tile load: 10 kg/m²

For further information on customised size models please contact Zentia Technical Sales.


Advisory note:


All statements and technical information contained in this brochure, or any publication of the companies named in this brochure, relating to Zentia are based on results obtained under laboratory test conditions.


It is the responsibility of the user to verify with the seller of the products in writing that such statements and information are appropriate to the specific use intended.


Sales of the products and liability of the selling companies are in accordance with the terms and conditions of sale of the selling company.


All product specifications are subject to modifications without prior notice.


























INS 221.1.08.24



zentia.com